

Manuale di istruzioni • Instruction manual





















Model name: FRD SPK2

Diffusore acustico wireless impiegabile in abbinamento a FREEDOM 2 o alla trasmittente mod. FRD TX. L'alta qualità dei componenti utilizzati per la sua realizzazione garantisce un'ottima resa acustica. L'installazione di questo prodotto deve essere effettuata esclusivamente da tecnici specializzati, competenti di impianti elettrici e di sonorizzazione. In caso di installazione o collegamenti errati il produttore non si assume alcuna responsabilità per danni a persone o cose. Nel caso installiate il diffusore all'aperto abbiate cura che esso sia riparato dalla pioggia diretta, posizionandolo sotto una tettoia o un pannello protettivo.



In caso di installazione all'aperto, assicuratevi che i connettori e l'alimentatore siano opportunamente isolati e non vengano quindi a contatto con umidità o pioggia.

Si suggerisce di proteggere il diffusore dai raggi diretti del sole per evitare il prematuro deteriorarsi delle plastiche.

Conservate il manuale di istruzioni per utilizzi futuri.

A. Posizionamento diretto a parete

Se intendete posizionare il diffusore a parete, potrete semplicemente agganciarlo ad un chiodo a "testa larga" grazie all'apposito foro di fissaggio(F). In questo caso il diffusore risulterà aderente alla parete ma non orientabile.

B. Posizionamento con staffa

La staffa inclusa nella confezione vi consentirà di fissare a parete il diffusore mantenendo la possibilità di orientarlo orizzontalmente e verticalmente per la massima resa acustica. La staffa è composta da 3 parti. Unitele utilizzando 2 viti, quindi fissate la staffa al diffusore (fori G), sempre tramite viti in dotazione.

Forate il muro assicurandovi che non vi siano cavi elettrici o tubi, quindi inserite 2 tasselli prima di fissare la staffa a muro. La regolazione avviene svitando leggermente le viti centrali, orientando a piacimento il diffusore e serrando nuovamente le viti centrali.

C. Alimentazione

Per alimentare il diffusore utilizzate il trasformatore incluso collegandolo al connettore (I). Assicuratevi che il connettore sia isolato (utilizzando ad esempio una guaina termoretrattile) e che il trasformatore sia protetto da umidità.



Attenzione: i collegamenti elettrici vanno effettuati da personale tecnico specializzato per evitare rischi di folgorazione o danneggiamento dell'apparecchio.

D. Utilizzo

Riferitevi al manuale di istruzioni del FRD TX o FREEDOM 2 per la corretta procedura di accoppiamento del diffusore alla trasmittente. Se necessario, potrete limitare il volume, agendo sul regolatore (H). La trasmittente potrà inviare il segnale a infiniti diffusori nel suo raggio operativo (FIG 1)

E. Conformità, garanzia e assistenza

Il fabbricante, KARMA ITALIANA SRL, dichiara che il tipo di apparecchiatura radio diffusore serie FRD SPK è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: www.karmaitaliana.it

Il prodotto è coperto da garanzia in base alle vigenti normative nazionali ed Europee. Per le condizioni complete di garanzia e per effettuare richieste di assistenza visitate il sito internet: www.glemm.eu Vi suggeriamo anche di procedere alla registrazione del prodotto, loggandovi nell'area riservata.

Il fabbricante, allo scopo di migliorare i propri prodotti, si riserva il diritto di modificarne le caratteristiche siano esse tecniche o estetiche, in qualsiasi momento e senza alcun preavviso.

CARATTERISTICHE TECNICHE / TECHNICAL SPECIFICATIONS	
Potenza Massima / RMS Max power/ RMS power	70W / 35W
Altoparlante / Speaker	Woofer 6,5"
Alimentazione Power supply	15V 2A tramite adattatore/ through adaptor
Risposta in frequenza Frequency response	20 Hz - 20 KHz
Impermeabilità / Waterproof rate	IP 44
Dimensioni / Dimensions	197 x 275 x 175 mm
Peso / Weight	2,1 Kg

PRODOTTO DA / PRODUCED BY:
KARMA ITALIANA Sri

Via Gozzano 38/bis 21052 Busto Arsizio (VA) www.karmaitaliana.it



Wireless audio speaker suitable to be used in combination with FREEDOM 2 or to the transmitter model FRD TX. The high quality of the components used for its construction guarantees an excellent acoustic performance. The installation of this product must be carried out exclusively by specialized technicians, skilled in electric and audio systems. In case of wrong installation or connections, the manufacturer doesn't take any responsibility for damages to people or objects. If you install the speaker outdoors, make sure that it is sheltered from direct rain by placing it under a canopy or a protective panel.



In case of outdoor installation, make sure that the connectors and the adaptor are adquately insulated and that they don't come into contact with humidity or water.

We suggest to protect the speaker from direct sunrays to avoid premature deterioration of the plastics.

Keep the instruction manual for future reference.

A. Direct wall mounting

If you wish to wall mount your speaker, you can just hang it on a wide head nail, thanks to the specific fixing hole (F).

In this case the speaker will be close to the wall, but it will not be possible to adjust it.

B. Wall mounting with bracket

Thanks to the bracket included in the package you can wall mount the speaker, mantaining the possibility to adjust it horizontally or vertically for maximum audio performance. The bracket is composed of 3 parts. Join them using 2 screws, then fix the the bracket to the speaker (G holes), always through the included screws. Drill the wall making sure that there are no electric cables or pipes, then insert two anchors before fixing the bracket to the wall. For adjustment, slightly unscrew the central screws, orienting at will the speaker and then tighten them again.

C. Power supply

To power the speaker use the included adaptor, by connecting it to the socket (I). Make sure that the connector is properly insulated (using for example a heat shrink sheath) and that the transformer is protected form humidity.



Warning: the electrical connections must be made by specialized technical personnel to avoid risks of electric shocks or damages to the fixture.

D. Use


Refer to the instruction manual of FRD TX or FREEDOM 2 for the correct procedure to pair the speaker to the transmitter. If necessary, you can limit the volume, by using the control (H). The transmitter can send the signal to an unlimited number of speakers in its operating range (PICT. 1)


E. Compliance, warranty and service

Hereby, KARMA ITALIANA SRL declares that the radio equipment type speaker FRD SPK series is in compliance with directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.karmaitaliana.it.

The product is covered by warranty according to current national and European regulations. For complete warranty conditions and for technical service requests visit the website: www.glemm.eu We also suggest to register your product, by logging into the website's private area.

The manufacturer, in order to improve its products, reserves the right to modify the characteristics whether technical or aesthetic, at any time and without notice







Lo smaltimento del prodotto deve essere effettuato conferendolo ad un apposito centro di raccolta differenziata (Dir 2012/19/UE)